

SMOKE ALARM OR CO MONITOR WON'T STOP MAKING NOISE



- 1. Usually this means the battery needs replacement. It is the resident's responsibility to replace the batteries in the smoke detector and CO monitor (if equipped). The battery that you replace it with must be a 9 Volt 10 year lithium battery. These are available at all hardware stores and most department and drug stores.
- 2. If the battery replacement does not solve the problem notify CPM as we will have to replace the unit.