



1. Locate the hot water tank.
2. If the tank is electric check the home's breaker box. Check to make sure the breaker is properly set (see HOW TO RESET A BREAKER). It will take a little time to determine if the water is heating up after resetting the breaker. If it doesn't notify CPM to report the problem.
3. If the tank is hooked up to gas, make sure you are in good standing with the gas company and the gas has not been shut off. If the gas is on, notify CPM to report the problem.